

PR-EH16

Контроллер

+12B	1
GND	2
D0/SIG	3
D1/SIG	4
LED-G	5
LED-R	6
Beep	7
HOLD/SYNC	8

Reader 1

1	+12B
2	Data 1
3	Data 2
1	LED
2	Beeper
3	GND

Reader 2

1	+12B
2	Data 1
3	Data 2
1	LED
2	Beeper
3	GND