

Режимы подключения DVR Optimus

Модель	Режим работы	Аналоговый режим		Сетевой режим				
		960Н	D1	1080P	960P	720P	960Н	D1
 <p>DVR-2008H</p>	1	8						
	2		8					
	3		4	1		3		
	4							16
	5			2		2		
	6			1		1	6	
	7					8		