




D811946\_02 29-10-12

## ДОПОЛНИТЕЛЬНАЯ ПЛАТА



ИНСТРУКЦИИ ПО УСТАНОВКЕ

B EBA SYMBIAN 4-8-16  
B EBA ANDROID 4-8-16




# U-link



AZIENDA CON SISTEMA DI GESTIONE  
INTEGRATO CERTIFICATO DA DNV  
= UNI EN ISO 9001:2008 =  
UNI EN ISO 14001:2004





### РУКОВОДСТВО ПО УСТАНОВКЕ

Эти платы совместимы только с блоками управления, использующими протокол U-link.

**Следовать инструкциям, приведенным в пользовательском руководстве к приложению.**

#### НАСТРОЙКИ НЕОБХОДИМЫЕ ДЛЯ РАБОТЫ

Логические функции на блоках управления	Настройки DIP-переключателя
Последовательный режим	0
Адрес	0
Пароль	Код ворот

#### ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

Температура рабочая	-20°/+50°C
Расстояние соединения макс. через Bluetooth между В ЕВА и смартфоном	20 м
Диапазон	2400 - 2483,5 МГц
Мощность макс.	Средняя макс. 30мВт EIRP
Размеры	42 x 29 мм (ДxШ)

#### BLUETOOTH устройства макс.

<b>В ЕВА SYMBIAN 4 / В ЕВА ANDROID 4</b>	4
<b>В ЕВА SYMBIAN 8 / В ЕВА ANDROID 8</b>	8
<b>В ЕВА SYMBIAN 16 / В ЕВА ANDROID 16</b>	16

**КОПИЯ АДМИНИСТРАТОРА**

**КОПИЯ ОТДАЕТСЯ ПОЛЬЗОВАТЕЛЮ**

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

User Name .....

Gate Code

User Code

